



Fan Replacement – Frames A-E


Installation Instructions
 Installationsanleitung
 Installation
 Installazione
 Instalación
 Instructies
 Instalação




Frame A
 Baugröße A
 Taille A
 Quadro A
 Tamaño A
 Frame A
 Gabinete A




Frame B
 Baugröße B
 Taille B
 Quadro B
 Tamaño B
 Frame B
 Gabinete B




Frame C
 Baugröße C
 Taille C
 Quadro C
 Tamaño C
 Frame C
 Gabinete C





Frame D
 Baugröße D
 Taille D
 Quadro D
 Tamaño D
 Frame D
 Gabinete D




Frame E
 Baugröße E
 Taille E
 Quadro E
 Tamaño E
 Frame E
 Gabinete E









- 3
- SK-M9-FAN1-ABCD1
 - SK-M9-FAN1-BD4
 - SK-M9-FAN1-E1
 - SK-M9-FAN1-E4




- SK-M9-FAN2-CDE1
- SK-M9-FAN2-D4




4 SK-M9-FAN2-CDE1
SK-M9-FAND-D4
SK-M9-FAN1-ABCD1



SK-M9-FAN1-E1
SK-M9-FAN1-E4



5



J2 / J3 / J4



www.rockwellautomation.com

Power, Control and Information Solutions Headquarters

Americas: Rockwell Automation, 1201 South Second Street, Milwaukee, WI 53204-2496 USA, Tel: (1) 414.382.2000, Fax: (1) 414.382.4444

Europe/Middle East/Africa: Rockwell Automation, Vorstaan/Boulevard du Souverain 36, 1170 Brussels, Belgium, Tel: (32) 2 663 0600, Fax: (32) 2 663 0640

Asia Pacific: Rockwell Automation, Level 14, Core F, Cyberport 3, 100 Cyberport Road, Hong Kong, Tel: (852) 2887 4788, Fax: (852) 2508 1846

Publication RA-IN014A-MU-P – January, 2005

P/N 360218-P01
Copyright © 2005 Rockwell Automation, Inc. All rights reserved. Printed in USA.